

STRESSVEST® *HIT KIT* GOGGLES

OVERVIEW

The Stressvest Hit Kit Goggles are designed to work exclusively with the CQT laser. Primarily developed for SWAT and Military, this system allows users to conduct close quarter training without the need to wear the normal Stressvest panels that may cover equipment being worn by the user.



StressVest® Hit Kit Goggles
SV-HSGOG-HK



StressVest® Hit Kit Goggles are ONLY compatible with Blank Fire CQT Lasers and CQT SIRT's.

P/Ns: SV-BFPLI-CQT01, SV-LGBML-CQT01 & SV-LGMP5ML-CQT01

Kit includes:



(A) Hit Kit Goggles



(B) Cable




(C) 18" Extender



(D) Transmitter Pouch

ASSEMBLY



- 1** Connect the Hit Kit Goggle's connector (A) to the green connector on the cable (B).



- 2** Connect the cable (B) to the StressVest® Transmitter*.



- 3** Sync the Transmitter to the StressX Pro Belt*. (Refer to the StressVest manual on how to sync the devices)



- 4** Insert the Transmitter into the Transmitter Pouch (D) and mount the pouch onto your kevlar vest or holster.

Note: If the Hit Kit Goggle's cable isn't long enough to reach the Transmitter, use the 18" extender (C).

CLEANING/MAINTENANCE

Clean only with mild soap and water. Do not use ammonia, window cleaner, or other solvents to clean the Hit Kit Goggles as they may degrade the integrity of these products.

**StressX Pro Belt and Transmitter are sold separately. StressVest® Hit Kit Goggles are compatible with your existing StressX Pro Belt and Transmitter.*